



Preliminary



2410 Midtown PL NE Suite A Albuquerque NM 87107 bira.com | info@bira.com | 505-881-8887

INNOVATIVE PRODUCTS THROUGH PARTNERSHIPS

1.0 Introduction

- 1.1 MCOR Crate Physical Description
- 1.2 MCOR Crate Functional Description
 - 1.2.1 Specification Features
- 1.3 Installation
 - 1.3.1 Power Requirements
 - 1.3.2 Rack Space
 - 1.3.3 Unpacking Units
 - 1.3.4 System configuration
 - 1.3.5 MCOR System Installation Assembly Diagram

2.0 MCOR Crate Interface Card

- 2.1 Overview
- 2.2 MCOR Interface Card Physical Description
- 2.3 MCOR Interface Card Functional Description
 - 2.3.1 Specification Features

3.0 MCOR Crate Cooling Unit

- 3.1 Overview
- 3.2 Features
- 3.3 Applications
- 3.4 General Description

4.0 MCOR Crate Cable Assembly Diagrams And I/O Tables

- 4.1 MCOR Crate Cable Assembly
 - 4.1.1 DC Power Input Cable Assembly Diagram (DWG. 2507)
 - 4.1.2 AC Bulk Power Input Cable Assembly Diagram (DWG. 2508)
 - 4.1.3 J3 Input Cable Assembly Diagram (DWG. 2503-J3)
 - 4.1.4 J4 Output Cable Assembly Diagram (DWG. 2504-J4)
 - 4.1.5 (J5-J8) Load Cable Assembly Diagram (DWG. 2509)
 - 4.1.6 J1 External Interlock Cable Assembly Diagram (DWG. 2506-J1)
 - 4.1.7 J2 Crate "OK" Cable Assembly Diagram (DWG. 2506-J2)
 - 4.1.8 MCOR 12 Input Signal Cable Assembly Diagram (DWG. J3-Signal)
 - 4.1.9 MCOR 12 Output Signal Cable Assembly Diagram (DWG. J4-Signal)
 - 4.1.10 MCOR 12 (16 channel) I/O Connector Wiring Pin-Out Table
 - 4.1.11 MCOR 30 (8 channel) I/O Connector Wiring Pin-Out Table
- 5.0 MCOR Backplane Schematic
- 6.0 Warranty

1.0 Introduction

This manual describes the Bi Ra System's Model 2513 – MCOR System Crate (A multi-channel corrector magnet driver system). The MCOR System provides precision bi-polar output currents with minimal zero-cross over distortion.

The manual is intended to describe the principle features, operations and specifications.

1.1 MCOR Crate Physical Description

The MCOR Model 2513 is a 19" rack mounted 6U x 220 mm crate. The crate has 17 slots; 16 (slot 0 thru 15) for the removable power modules (MCOR 12 and MCOR 30) and the far left slot control system interface card Model 2512-C4. The control slot employs two 96-pin VME connectors and the 16 power slots have single 48-pin connectors on the backplane to achieve a modular architecture.

The MCOR power modules slide into standard card rails and two locking extractor handles hold each module in place. The power modules are access by twisting two ¼ turn captive fastens and lowering a single hinged clear lexan front cover. The crates front cover provides safety during operation and a positive air flow for cooling.



Figure 1: Shows MCOR crate load with 16 Power Modules and interface card on far left.

1.2 MCOR Crate Functional Description

The MCOR Crate's interface/control card (Model 2512-C4) communicates with the outside world thru connectors J1 (ExtIntlk), J2 (CrateOK), J3 (Input Reference Voltages), J4 (Output Monitors), and J9 (Bitbus) on the rear backplane of the crate (see figure 1.2 below). The interface card may be either analog or digitally based, depending on the end-users individual control system requirements. Each power module provides the control card with an independently derived monitor signal, to verify that all correctors are operating within the specified tolerance.

The MCOR's backplane (4 layer) provides all of the power and signal connectivity between the power modules, the control card and the outside world. A single unipolar bulk power supply provides the main DC power to the crate through the 180A Powerpole connector (DC Power Input) on the rear panel. This connector is attached internally to a pair of PCB mount busbars that distribute the bulk DC power across the backplane. The +5, +15 and -15 utility voltages are distributed via standard copper traces to the individual modules through the backplane. A standard 48-pin, type "E" DIN connector provides the signal and power connections from the backplane to each power module. The interface card connects to the backplane using a VME format for connector arrangement, positioning, and module width. No internal chassis wiring is necessary. All other external connections, including the outputs to the magnets and the control system cables, are accomplished through PC mounted connectors on the backplane. The crates are tested and certified on fixtures that emulate actual load conditions.

The MCOR system employs a modular architecture, so that any individual channel is serviceable without disturbing the operation of adjacent channels in the same crate.

1.2.1 MCOR Crate Enclosure Specifications

Dimensions:	19" rack mount, 10.50" height, 21.50" depth.
Cooling:	Recommend Bi Ra Model 4922 Blower (330 CFM)
Weight:	25 lb. (11.3kg)



Figure 1.2

1.3 Installation

The following items are required to install a fully powered and cooled MCOR Crate (model 2513).

1.3.1 Power Requirements

Single phase 115 VAC is required MCOR Crate utility power and blower unit (Model 4922 is recommended). Bi Ra Systems technical staff will be pleased to assist on the selection of the single unipolar bulk power supply which provides main power to the crate.

1.3.2 Rack Space

A standard 19" rack with minimum of (12V) of vertical space and 24" depth (Bulk Power Supplies tend to range from 20" to 24").


1.3.3 Unpacking Units

Carefully unpack units and check for any damage that might have occurred through shipment. MCOR Crate and blower should have a standard power cord each (115 VAC) with shipment. Guide rails in crate should be inspected after shipment to insure proper sitting.

1.3.4 Systems Configuration

A standard configuration of MCOR System assembly is shown in figure 1.3.1.

1.3.5 Crate Cable Assembly



2.0 MCOR Crate Interface Card

2.1 Overview

The MCOR corrector chassis must interface with different types of control systems presently in use. In order to accommodate these control schemes, as well as any future configurations, the MCOR crate architecture places the total control system interface on a single VME-standard card. This interface card occupies the left-most slot of the crate. It is responsible for monitoring voltage reference inputs, output voltages and fault conditions.

2.1 MCOR Interface Card Physical Description

The Bi Ra Model 2512-C4 interface card is a standard VMEbus-compatible 6U by 220 mm board installed in slot 0 in an Eurocard crate. Two 96-pin I/O connectors connect the interface card to the MCOR crate's backplane. The Interface card (see figure 2.0) employs sixteen test jacks in the front of the card to enable local measurement of the MCOR output currents. A second set of front test jacks enable local measurements of the reference voltages. A front mounted reset switch sets the interface's Crate OK latch and resets the MCOR's fault protection latch. An optional crate door switch sets the Inhibit Bus to the Inhibit state when the crate door is opened.

2.3 MCOR Interface Card Functional Description

The Model 2512-C4 Crate Interface card functions as a control-monitor interconnect between an MCOR magnet driver crate backplane, current set-point reference voltages, system fault/enable discrete lines and magnet-current monitoring signals input to a analog monitor. The Interface card can be used in sixteen Bi Ra 2510 (MCOR12) systems or eight 2510R30 (MCOR30) systems.


The interface card provides a simple, inexpensive, application-adaptive capability for magnet power systems by concentrating control-protective circuitry on a single card that can be adapted to system control/monitoring requirements. This simplifies interfacing in a diversity of control and monitoring regimes because the MCOR magnet driver modules need not to have the specialized circuitry for interfacing to the many possible control system implementations.

2.3.1 MCOR Interface Card Specification Features

Figure 2.0

System Bus Signals, all to/from the crate backplane

- Reset Bus A high-true, TTL-level, single ended logic signal, typically input to the backplane by external equipment or by actuation of the Reset Switch.
- Crate OK A differential logic signal from an RS485 driver. If the Crate OK latch is set, the crate OK+ line is TTL-high and the OK- line is TTL low.
- Inhibit Bus A high true, TTL-level, single ended logic signal, input to the crate backplane via the Crate Interlock BNC connector by external equipment or by actuation of the crate door-switch.



- MCOR Faults Sixteen, TTL-level, low-true fault signals from the MCOR power modules; any fault resets the "Crate OK" latch.
- External Interlock A high-true TTL-level signal that is a summation of the readiness states of external equipment.
- Reference Voltages are +/- 10Volt bipolar voltages from external reference voltage power supplies that determine the MCOR's current set-point.

3.0 MCOR Crate Cooling Unit

3.1 Overview

The crate is completely air-cooled, using standard rack mounted fans and plenums that draw in cool air from the aisle through a filter. The air is then pushed up through the crate and into the rack, keeping the rack interface at positive pressure.

- 3.2 FEATURES
- 2U Chassis 19" rack mount 3.48" Height, 9.60" Depth.
- Weight 6lb.
- Power 120V AC 60Hz
- Washable front removable air filter
- Ball Bearing AC fans provide 330 CFM
- Dual plenum design

3.3 APPLICATIONS

- Cooling for 160mm,220mm depth modules
- Diverts lower warmed air to rear of Cabinet
- RM option diverts lower air to front of Cabinet

TERRITOR OF A








Rear View of Model 4922 shown

3.4 General Description

The Model 4922 blower is a 19" rack mountable (2U) unit that was designed to cool 160mm or 220mm depth modules. The bottom air plenum diverts the air from below to rear of cabinet. The top plenum distributes the airflow more uniformly across the bottom of the crate to enhance the units cooling capabilities. This unit draws the cooling air through a front foam filter which is easily removable for cleaning while in operation. The chassis is rugged in construction and features long life Ball Bearing AC fans.








1 1 2 AMP 2038163 0	ر	_	Т	U	ш	ш		U	A B	
THE PARTS LIST: THE PA	10							i	M M Sheet 1 Sheet 1	10
The second secon	σ		4 B						Bi Ro MCOR , ASSEh D 7/15/0	6
The second secon	DRAWING								BY DRAWN JENTA JIBY OHEOKIN JENTA JIDYUOO OHEOKIN AAPPROVALS PEDICICI AAPPROVALS APPROVALS MICT ITTES MICT MICT MICT MICT MICT MICT MICT MICT	ω
A A A A A B A A A A A A A A A A A A A A				¥					RECISION CONTROL# AINTING: and The LUNT:	2
A A A A A A A A A A A A A A	ω			BLACK SHRIN TUBING (1")			QUANITY	36 1 - 1 - 1 AR		9
A A A A A A A A A A A A A A	ى س						Z	- ONNECTOR HOOD &AY JACKET INK TUBING	VECTIONS. RMINATED. D.	5
A A A A A A A A A A A A A A	4			, }	>		DESCRIPTIO	PIN CONTACT 6 POSITION C CONNECTOR AULTIPAIR, GF BLACK SHR	IVIDUAL CONI IS LEFT UNTE USER DEFINE	4
4.1.3 PAGE 12	ю П		4A)			PART#		RIMP FOR IND DF CABLE(4B) CABLES ARE	с
4.1.3 PAGE 12	7							AMP 2(AMP 2(AMP 2(6089/15 1/2" DIA	S: FRIP AND C THER END (:NGTHS OF	2
	-						PART5 ITEM⊭	- ი ი 4 ი	ž	-
		_	Т	U	Щ			U		

Image: Second	_ -	– <u> </u>	ш О	U		
TIUBING (1) A BLACK SHRINK FRY AGRIENT FARTS LIST: FARTS LIST: FRY AGRIENT FRY AGRIENT FR					Inc. CABLE RAM J4 REV Sheet 1	10
Image: Second	σ	2B			Bi Ra S MCOR J4 C ASSEMBL D 7/15/04 ^{bu} NTS Mechania	6
Image: Second	DRAWING				PRAMIN ELITIA URBOD PHECKED REQUECT REQUECT RELECT APPROVIALS APPROVIALS APPROVIALS APPROVIALS	8
TIUBING (1" PARTS LIST: TIUBING (1" PARTS LIST: TIEM# PART# DESCRIPTION TIUBING (1" PARTS LIST: TIEM# PART# DESCRIPTION AUAUTIY PARTS LIST: PARTS LIST:					RECISION CONTROL#	7
1 2 3 1 2 3 1 2 3 1 2 2 1 2 3 2 3 3 3 3 2039/16-3 3 3 3 4 10 205083-3 3 3 204744-1 3 3 3 4 10 205083-3 3 10 205083-3 4 10 205083-3 3 10 205083-3 3 10 205083-3 3 10 205083-3 1 3 204744-1 3 3 2018 1 3 204744-1 3 3 205083-3 3 1 2 3 1 2 3 1 3 3 1 3 3 3 3	۵ 	BLACK SHRIN TUBING (1")	QUANITY	36 1 1 1 AR		9
1 2 3 1 2 3 1 2 3 1 2 2 1 2 3 2 3 3 3 3 2039/16-3 3 3 3 4 10 205083-3 3 3 204744-1 3 3 3 4 10 205083-3 3 10 205083-3 4 10 205083-3 3 10 205083-3 3 10 205083-3 3 10 205083-3 1 3 204744-1 3 3 2018 1 3 204744-1 3 3 205083-3 3 1 2 3 1 2 3 1 3 3 1 3 3 3 3	ى س			NNECTOR OOD Y JACKET IK TUBING	ECTIONS. MINATED.	5
1 2 3 1 2 3 1 2 3 1 2 2 1 2 3 2 3 3 3 3 2039/16-3 3 3 3 4 10 205083-3 3 3 204744-1 3 3 3 4 10 205083-3 3 10 205083-3 4 10 205083-3 3 10 205083-3 3 10 205083-3 3 10 205083-3 1 3 204744-1 3 3 2018 1 3 204744-1 3 3 205083-3 3 1 2 3 1 2 3 1 3 3 1 3 3 3 3	4		ESCRIPTION	N CONTACT POSITION CO DNNECTOR H ILTIPAIR, GR ² BLACK SHRIN	IDUAL CONNI SLEFT UNTEF SER DEFINED	4
4.1.4 PAGE 13	m			_	AP FOR INDIV CABLE(5B) IS ABLES ARE U	З
4.1.4 PAGE 13	N			AMP 2038 AMP 2047 AMP 2050 6089/18C 1/2" DIA	RIP AND CRIN HER END OF VGTHS OF C/	2
	<i>-</i>		PARTS ITEM#	- 0 ω 4 ₪	ž	1
		- I O L		0		



	Bi Ra Systems J1 EXTERNAL INTE CABLE ASSEMBLY D CABLE ASSEMBLY D D 7/16/04 [bwc.wo. 2506- NTS [Mechanical DWG]	8 9 10
REVISION HISTORY: 8 A ORIGINAL DRAWING B 0RIGINAL DRAWING	A ANTING: 	2
	A T C	5 6
	LIST: EM# PART# DESCRIPTION 957 12UG-88A/U MALE BNC 2 9201 MALE BNC RG 58/U CABLE 2 9201 RG 58/U CABLE RG 58/U CABLE 3. LENCLOW BNC DIRECTIONS FOR ASSEMLY. 2. OTHER END OF CABLE(6B) IS LEFT UNTERMINATED. 3. LENGTHS OF CABLES ARE USER DEFINED.	4
	IS LIST: ITEM# PART# DESCRIPTIC 1 957 12UG-88A/U MALE BNC 2 9201 RG 58/U C/ NOTES: 1. FOLLOW BNC DIRECTIONS FOR ASSEMLY. 2. OTHER END OF CABLE(6B) IS LEFT UNTER 3. LENGTHS OF CABLES ARE USER DEFINED	2 3
	QE Ž	1

		_	Т	U	ш	ш	D	Ö	<u> </u>	
9 10		7 B							Bi Ra Systems Inc. J2 CRATE "OK " CABLE ASSEMBLY DIAGRAM D] 7/16/04 0ms. No. 2506-J2 REX NTS Mechanical DWG. 5neet 1	9 10
8 ISTARY-	ORIGINAL DRAWING								DRAVIM RENTE BY CHECKED Anatran CHECKED Anatran Anatra	8
REVISION HISTORY-	A ORIGI	_		-					PRECISION CONTROL# PAINTING: 1aa. 1aa.	7
9				T				duanii y 1 AR		6
5							ī	JN ABLE	MINATED.	5
4								DESCRIPTION MALE BNC RG 58/U CABLE	OTES: 1. FOLLOW BNC DIRECTIONS FOR ASSEMLY. 2. OTHER END OF CABLE(7B) IS LEFT UNTERMINATED 3. LENGTHS OF CABLES ARE USER DEFINED.	4
с								PAKI# 957 12UG-88A/U 9201	DIRECTIONS F CABLE(7B) CABLES ARE	3
2								957 12L 9201	S: DLLOW BNC I THER END O ENGTHS OF (2
-				(AL		4.1.7	PARTS LIST:	11 EM#	NOTES: DOTES: 2. OTES: 2. OTES: bode 16	-
	7	_	Т	U	ш	ш		U	<u>۵</u> ح	

		٦			_	-			3	5			ი				ш				Ц	J			۵				U				۵				۷		_
10		40 FEET	36 PCS	1 EA	1 EA																												ame Inc	PLIT SIGNAL	ASSEMBLY DIAGRAM		Sheet		10
6		BELDEN 1091A	AMP 203816-3	AMP 204744-1	AMP 205083-3														MCOR-13/P-CAB40														H Bi Ba Sveteme Inc	MCOR 12 13 INDUT SIGNAL		D 7/16/04 DWG. NO.			6
8	PART LIST		0																		K					Þ]						CHECKED Andree APPROVALS	PROJECT MFG STRESS	MET DRB	MATERIAL:		8
2		CABLE 20PR 20GA IND+0/A SHIELD	CONN PIN CONTACT 20-24AWG CRIMP	ONNECTOR																			0			Þ								PRECISION CONTROL#	PAINTING:	QTY PER UNIT:	-04.		7
9	DESCRIPTION	CABLE 20PR 2	CONN PIN CON	36 POSITION CONNECTOR	CONN HOOD																														SYNC INPUT SIGNAL		•	Z	9
5	A + REF 0		+ REF 1	- REF 1		- REF 2	+ REF 3	- REF 3	+ REF 4	- REF 4	+ REF 5	- REF 5		+ REF 6		+ REF 7		+ REF 8	- REF 8	+ REF 9	- REF 9	+ REF 10	- REF 10	+ REF 11	- REF 11		+ REF 12	- REF 12	+ REF 13	- REF 13	+ REF 14	- REF 14	+ REF 15	- REF 15	SYNC INP			V - RESET BUS	V 5
4																							-RED	-RED	-WHT		-WHT	-WHT	-WHT	-GRN	-GRN	-GRN	-ORN	-GRN	-ORN	-ORN	-ORN	-BLU	4
3	BLK	WHITE	RED	GRN	ORN	BLU	WHT-BLK	RED-BLK	GRN-BLK	ORN-BLK	BLU-BLK	BLK/WHT	-	RED-WHT	GRN-WHT	BLU-WHT	BLK-RED	- WHT-RED	ORN-RED	BLU-RED	RED-GRN	ORN-GRN		WHT-BLK-RED	RED-BLK-WHT	Ţ	GRN-BLK-WHT	ORN-BLK-WHT	BLU-BLK-WHT	BLK-RED-GRN	WHT-RED-GRN	RED-BLK-GRN	GRN-BLK-ORN	ORN-BLK-GRN	BLU-WHT-ORN			ORN-WHT-BLU	
2	INPUTS J 3	CH 0 $\frac{A1}{\Delta 2}$	T	CH 1 A 4		CH 2 A 6		CH 3 A 8		CH 4 A 10		CH 5 A 12		B 1	CH 6 B 2		CH 7 B 4		CH 8 B		$CH = \frac{D}{D}$		CH 10 $\frac{D_3}{D_{10}}$		CH 11 B 12			CH 12 CH	╀	CH 13 C 4	+	CH 14 $\overline{c6}$	+	CH 15 $\frac{\overline{c}}{c8}$		1		EI BUS C 12	2
1																																			EXT SYNC BUS	SYNC INPUT RETURN		EXI RESEI BUS	-
																			,			1.8														pag	ge 1	17	
		ſ			-	-				-			G				ш				Ш	J			Δ				C				ш				۲		

<u> </u>		ר			-	-				Т			ტ				Ш				Ц	IJ			C	د د			U				В				۲		٦
10																																	Bi Ra Systems Inc.	OUTPUT SIGNAL	MBLY DIAGRAM	DWG. NO. REV. J4-SIGNAL REV.	al DWG. Sheet 1		10
6		A0 FEET	(n)		1 EA														MCOR-14/P-CAB40														Bi Ra Sy	MCOR 12 J4 OUTPUT	CABLE ASSEMBLY	D 7/16/04 04	NTS Mechanical DWG.		6
8	PART LIST	BELDEN 1091A	AMP 203816-3	AMP 204744-1	AMP 205083-3														MCO			\succ	,										BY NITA JURADO				2		8
		VD+0/A SHIELD	CONN PIN CONTACT 20-24AWG CRIMP	CTOR																						Þ							ROL# DRAWN BE	CHECKED And	PROJECT MFG STRESS	DRB			
2	DESCRIPTION	CABLE 20PR 20GA IND+0/A SHIELD	NN PIN CONTACT	36 POSITION CONNECTOR	CONN HOOD															Ĺ			•			Þ							PRECISION CONTROL#		PAINTING:	QTY PER UNIT: 1ea.			2
9	DE	CA	8	36	00																																PWR GND OR CHASSIS GND		9
5	0 MON 0	GND 0	MON 1	GND 1	MON 2	GND 2	MON 3	GND 3	MON 4	GND 4	MON 5	GND 5		MON 6	GND 6	MON 7	GND 7	MON 8	GND 8	6 NOM	GND 9	MON 10	GND 10	MON 11	GND 11		MON 12	GND 12	MON 13	GND 13	MON 14		MON 15	GI UND 15		+ HVDC (F)		Λ	5
4																																							4
3	BLK	WHITE	RED	GRN	ORN	BLU	WHT-BLK	RED-BLK	GRN-BLK	ORN-BLK	BLU-BLK	BLK/WHT		RED-WHT	GRN-WHT	BLU-WHT	BLK-RED	WHT-RED	ORN-RED	BLU-RED	RED-GRN	ORN-GRN	BLK-WHT-RED	WHT-BLK-RED	RED-BLK-WHT		GRN-BLK-WHT	ORN-BLK-WHT	BLU-BLK-WHT	BLK-KED-GKN	WHI-KEU-GKN	KEU-BLA-GRN	GRN-BLK-ORN	OKN-BLK-GKN	BLU-WHI-ORN	WHT-RED-ORN	ORN-WHT-BLU		3
2	OUTPUTS J 4											_ب د		LB1									CH 10 B 40		CH 11 B 12	0		CH 12 $\overrightarrow{C2}$			cu 1 1 C 5	C 6	CU 4E C7	80	60	C 10			2
	<u>1</u> 0	CH 0		CH 1		H		CH	I	CH 4		Ю	1		CH 6		CH 7	I	CH 8		CH 9		Э		CH	1		Э	1 5	CI	12	5	1 2	5	I			1	_
-		<u>_</u>		1				1		T		1										.1.9 ⊔	9	1					0		-1		В		-1	pag	e 18	3	-
		-		1				i –		-		1	0									-		1	_	-											•		

J4 OUTPUT "SAM"

	А	В	C
1			
2			
3	Monitor 0	Monitor 3	Monitor 6
4	Common 0	Common 3	Common 6
5			
6			
		Ο	
7	Monitor 1	Monitor 4	Monitor 7
8	Common 1	Common 4	Common 7
9			
10			
11	Monitor 2	Monitor 5	? Ground ?
12	Common 2	Common 5	? Ground ?

J3 INPUT "DAC"

	А	В	C
1			
2			
3	+Reference 0	+Reference 3	+Reference 6
4	-Reference 0	-Reference 3	-Reference 6
5			
6			
		Ο	
7	+Reference 1	+Reference 4	+Reference 7
8	-Reference 1	-Reference 4	-Reference 7
9			
10			
11	+Reference 2	+Reference 5	
12	-Reference 2	-Reference 5	

DC Output Connectors (looking at rear of crate, Pin # and Channel/Polarity)

J	8	J	7	J	6	J	5
H - 7 +	A – 6-	H - 5+	A – 4-	H - 3 +	A – 2-	H - 1 +	A – 0-
G – 7-	B – 6+	G – 5-	B-4+	G – 3-	B – 2+	G – 1-	B - 0 +
F – 7+	C – 6-	F – 5+	C – 4-	F – 3+	C – 2-	F – 1+	C – 0-
E – 7-	D - 6+	E – 5-	D-4+	E – 3-	D – 2+	E – 1-	D – 0+

4.1.11 MCOR 30 (8 channel) I/O Connector Wiring Pin-Out Table

J4 OUTPUT "SAM"

	А	В	C
1	Monitor 0	Monitor 6	Monitor 12
2	Common 0	Common 6	Common 12
3	Monitor 1	Monitor 7	Monitor 13
4	Common 1	Common 7	Common 13
5	Monitor 2	Monitor 8	Monitor 14
6	Common 2	Common 8	Common 14
		Ο	
7	Monitor 3	Monitor 9	Monitor 15
8	Common 3	Common 9	Common 15
9	Monitor 4	Monitor 10	
10	Common 4	Common 10	
11	Monitor 5	Monitor 11	Ground
12	Common 5	Common 11	Ground

J3 INP<u>UT "DAC"</u>

А	В	C
+Reference 0	+Reference 6	+Reference 12
-Reference 0	-Reference 6	-Reference 12
+Reference 1	+Reference 7	+Reference 13
-Reference 1	-Reference 7	-Reference 13
+Reference 2	+Reference 8	+Reference 14
-Reference 2	-Reference 8	-Reference 14
	Ο	
+Reference 3	+Reference 9	+Reference 15
-Reference 3	-Reference 9	-Reference 15
+Reference 4	+Reference 10	
-Reference 4	-Reference 10	
+Reference 5	+Reference 11	
-Reference 5	-Reference 11	
	+Reference 0 -Reference 0 +Reference 1 -Reference 2 -Reference 2 -Reference 3 -Reference 3 +Reference 4 -Reference 4 -Reference 5	+Reference 0+Reference 6-Reference 0-Reference 6+Reference 1+Reference 7-Reference 1-Reference 7+Reference 2+Reference 8-Reference 2-Reference 8-Reference 3-Reference 9+Reference 3-Reference 9+Reference 4+Reference 10-Reference 5+Reference 11

DC Output Connectors (looking at rear of crate, Pin # and Channel/Polarity)

J8		J7		J6		J5	
H –15+	A –12-	H –11+	A – 8-	H – 7+	A – 4-	H – 3+	A – 0-
G –15-	B-12+	G –11-	B – 8+	G – 7-	B-4+	G – 3-	B – 0+
F - 14+	C –13-	F - 10+	C – 9-	F - 6+	C – 5-	F - 2+	C – 1-
E – 14-	D –13+	E – 10-	D – 9+	E – 6-	D – 5+	E – 2-	D – 1+

5.0 WARRANTY

Equipment manufactured by Bi Ra Systems for use in the United States is warranted against defects in design, workmanship, and materials for a period of one (1) year from the date of shipment. Bi Ra Systems will repair or replace, at its option, any such equipment found to be defective on a return to factory basis. Repair charges will be applicable after the warranty period has expired. Transportation charges for shipping the equipment to Bi Ra Systems shall be paid by the customer, while transportation charges for the return of the repaired equipment will be paid by Bi Ra Systems. Priority shipping methods are available at the customer's expense. SOFTWARE products by Bi Ra Systems are furnished under the terms and conditions of a separate Software Product License Agreement is warranted for a period of ninety (90) days from the date of shipment to conform to the Software Product Description (SPD) applicable at the time of purchase. This warranty is contingent upon the proper use of the SPD. PRODUCTS PURCHASED BY BI RA SYSTEMS FOR RESALE WILL CARRY THE ORIGINAL EQUIPMENT MANUFACTURER'S WARRANTY, IF ANY.

These warranties shall not apply to equipment or software that has been modified or serviced by other than a Bi Ra Systems or an authorized distributor service engineer.

All warranties are contingent upon proper use of the product or system. These warranties will not apply (i) if adjustment, repair or parts replacement is required because of accident, unusual physical, electrical, or electro-magnetic stress, neglect, misuse, failure of electric power, air conditioning, humidity control, transportation, failure to rotating media not furnished by Bi Ra Systems, operation with media not meeting or not maintained in accordance with Bi Ra Systems specification or causes other than ordinary use; or (ii) if the product or system has been modified by the purchaser; or (iii) where Bi Ra Systems serial numbers or warranty date decals have been removed or altered. In addition to the forgoing, any application on-site warranty will not apply (i) if prerequisite equipment (as specified by Bi Ra Systems price list, equipment specifications, or contract(s) is missing, or (ii) if the product or system has been installed by the purchaser without the supervision of or prior written approval of Bi Ra Systems. Equipment may contain used parts which are equivalent to new in performance when used in the equipment. BI RA SYSTEMS MAKES NO WARRANTY OR MECHANTABLILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY EITHER EXPRESS OR IMPLIED, EXCEPT AS IS EXPRESSLY SET FORTH HEREIN.

Outside the United States, the equipment warranty is limited to the replacement of the equipment and excludes shipping, insurance, taxes, forwarders' fees, customs, or any other charges.

THE WARRANTY PERIOD MAY VARY IN COUNTRIES OUTSIDE THE UNITED STATES. CONTACT BI RA SYSTEMS OR YOUR LOCAL AUTHORIZED DISTRIBUTOR FOR SPECIFIC WARRANTY DETAILS.

LIMITATIONS OF LIABILITY

The purchaser's exclusive remedy or any claim of any kind for loan or damage connected with, or resulting from the design, manufacture, sale, delivery, resale, or repair or use of any products furnished by Bi Ra Systems including but not limited to any claim of negligence or other breach, shall be the repair or replacement, F.O.B. factory, of the product or part thereof giving rise to such claim. Bi Ra Systems liability for such repair or replacement shall in no event exceed the contract price allocable to the products or part which gives rise to the claim. Bi RA SYSTEMS SHALL IN NO EVENT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

RETURN OF PRODUCTS

Bi Ra Systems must be notified before any product is returned for any reason. The Customer Service Department must issue a Return Material Authorization (RMA) number before any product can be accepted for credit, exchange, or repair. In order to provide an RMA number, Customer Service will need the complete model number, serial number, original purchase order number, and details regarding the reason for return and the service required.

All returns for CREDIT or EXCHANGE are subject to Bi Ra Systems approval and will incur a minimum restocking charge of ten (10) percent, as well as any incoming transportation charges or other fees incurred by Bi Ra Systems.

All returns for WARRANTY REPAIR must include a description of the problem and the name of a technical contact in case the problem must be discussed. If the product is out of warranty, the customer must contact Bi Ra Systems for an estimate of the repair charges and include a purchase order number for the estimated repair charges.

Transportation charges for shipping the products to Bi Ra Systems shall be paid by the customer. Transportation charges for the return of the products that have be exchanged shall be paid by the customer, while transportation charges for the return of the repaired equipment will be paid by Bi Ra Systems. The return shipment will be by UPS services, air freight, or truck. Premium methods of shipment are available at the customer's expense and will be used only when requested. If Bi Ra Systems selects the carrier, Bi Ra Systems will not thereby assume any responsibility or liability in connection with the shipment nor shall the carrier be in any way construed to be the agent of Bi Ra Systems.

After obtaining a Return Material Authorization (RMA) number, customers should return the product to:

BI RA SYSTEMS, INC. 2410 Midtown PL NE ALBUQUERQUE, NEW MEXICO 87107 TELEPHONE: (505) 881-8887 FAX: (505) 888-0651